



Connect your positive and negative power to the large wires. It does not matter which wire gets positive or negative.

Isolate the 3 small wires, they are not used.

Note: Do not connect the 3 small wires together as it will cause a short. Be sure to isolate them individually.