

Below is a representation of the white plug that is pre-wired with the motor.

- The White wire coming from the cord connects to the White wire coming out of the motor.
- For clockwise rotation, place a jumper between the Black and Red wires on the plug.
- For counterclockwise rotation, place a jumper between the Black and Blue wires on the plug.

