


## Plumbing for Loader Applications

Work Port B2  
To Base End of  
Bucket Cylinder

Work Port A2  
To Rod End of  
Bucket Cylinder

Work Port A1  
To Base End of  
Boom Cylinder

Work Port B1  
To Rod End of  
Boom Cylinder



For open center configuration, remove the power beyond sleeve and replace it with a SAE 8 plug.

Power beyond configuration

### Dimensions and Movement Scheme

