
SURPLUS CENTER





To reverse motor direction:

Internally, the wires on the brushes must be swapped from Post 1, to Post 2(&Post 2 to Post 1). Both wires on post 2 must be moved to post 1. The wires are to short to reach and will need to be lengthened.

Surplus Center www.surpluscenter.com