



Note: Be sure to remove any paint between the solenoid and the piece you are mounting it to. Without a good ground this unit will not function properly.