



Hall Sensor

24 Volts DC

Interchange the + and Ground wires to reverse the actuator.