



Energizing Solenoid 1 directs pressure out of Port A.
Energizing Solenoid 2 directs pressure out of Port B.