


NOTE:
Do not connect field coils
if using a permanent
magnet motor.



* NOTE: Do not add fuse to L2 unless input voltage is 240 VAC.