


**NOTE:**  
Do not connect field coils  
if using a permanent  
magnet motor.



\* NOTE: Do not add fuse to L2 unless input voltage is 240 VAC.